

## 1. Introduction

EX-9017 series is a analog input module with 8 input channels. It can select 8 channels all are differential type or 6 of the eight channels are differential & other two are single ended type.

Specifications:

Interface: RS-485, 2 wires

Speed (bps): 1200, 2400, 4800, 9600, 19.2K, 38.4K, 15.2K

Analog Input type: 8 differential/ 6 differential & 2 single ended

Analog Channels Numbers: 8

Analog Resolution: 16 bits (12bits for 9017F series)

Unit Conversion:  $\pm 10\text{V}$ ,  $\pm 5\text{V}$ ,  $\pm 1\text{V}$ ,  $\pm 500\text{mV}$ ,  $\pm 150\text{mV}$ ,  $\pm 20\text{mA}$

Sampling Rate : 10 Samples/Second

Bandwidth : 15.7 Hz

Accuracy :  $\pm 0.1\%$

Zero Drift :  $0.5\mu\text{V}/^\circ\text{C}$

Span Drift :  $25\text{ppm}/^\circ\text{C}$

CMR@ 50/60Hz : 150dB

NMR@ 50/60Hz : 100dB

Input Impedance : 20M Ohms

Current Measurement:  $\pm 20\text{mA}$  (with external 125 ohms resistor)

Power supply: +10V to +30V



# Specifications


	EX-9017F	EX-9017R	EX-9017FR
<b>Interface</b>	RS-485, 2 wires		
<b>Speed(bps)</b>	1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200		
<b>Analog Input type</b>	6 differential input & 2 single ended input		
<b>Input Channels</b>	8		
<b>Resolution</b>	16/12 bits	16 bits	16/12 bits
<b>Voltage Input</b>	-10V ~ +10V -5V ~ +5V -1V ~ +1V -500mV ~ +500mV -150mV ~ +150mV		
<b>Current Input</b>	-20mA ~ +20mA (with 125ohms resistor)		
<b>Sampling Rate</b>	10/50Hz	10Hz	10/50Hz
<b>Bandwidth</b>	15.7Hz		
<b>Accuracy</b>	±0.1%		
<b>Zero Drift</b>	0.5μV/°C		
<b>Span Drift</b>	25ppm/°C		
<b>CMR@50/60Hz</b>	150dB		
<b>NMR@50/60Hz</b>	100dB		
<b>Input Impedance</b>	20M ohms		
<b>Power supply</b>	+10V ~ +30V		
<b>Over voltage protection</b>	Not support	240Vrms	

## Notes:

1. Warm-UP for 30 minutes is recommended before starting operation!
2. EX-9017F: EX-9017 w/ fast mode (12bits)
3. EX-9017FR: EX-9017 w/ fast mode (12bits) & 240Vrms over voltage protection



# 1.2 Wire connection

## 1.2.1 Block Diagrams





## 1.2.2 Wiring diagram for the EX-9017 series



**EX9017F Analog I/P Channel 0 to 5 wire connection**



**EX9017/17F** Analog I/P Channel 6 and 7 wire connection, while the jumper JP1 setting is 8 differential mode.



**EX9017F** Analog I/P Channel 6 and 7 wire connection, while the jumper JP1 setting is Init\* mode.



## 1.3 Default Settings


Default settings for the EX-9017/17F/17R/17FR modules are as follows:

- . Module Address: 01
- . Analog Input Type: type 05
- . Baud Rate: 9600 bps
- . Checksum disabled
- . Engineering unit format
- . Filter set at 60Hz rejection

## 1.4 INIT\* Mode Operation

Each EX9000 module has a build-in EEPROM to store configuration information such as address, type, baudrate and other information. Sometimes, user may forget the configuration of the module. Therefore, the EX9000 have a special mode named "INIT\* mode" to help user to resolve the problem. The "INIT\* mode" is setting as Address=00, Budrate=9600bps, no Checksum .

Originally, the INIT\* mode is accessed by connecting the INIT\* terminal to the GND terminal. New EX9000 modules have the INIT\* switch located on the rear side of the module to allow easier access to the INIT\* mode. For these modules, INIT\* mode is accessed by sliding the INIT\* switch to the Init position as shown below.



To enable INIT\* mode, please following these steps:

Step1. Power off the module

Step2. Connect the INIT\* pin with the GND pin.

(or sliding the INIT\* switch to the Init\* ON position)

Step3. Power on

Step4. Send command \$002 (cr) in 9600bps to read the Configuration stored in the module's EEPROM.

There are commands that require the module to be in INIT\* mode. They are:

1. %AANN TTCCFF when changing the Baud Rate and checksum settings. See Section 2.1 for details.

## 1.5 Module Status for DIO, AIO

**Power On Reset** or **Module Watchdog Reset** will let all output goto **Power On Value**. And the module may accept the host's command to change the output value.

**Host Watchdog Timeout** will let all output goto **Safe Value**. The module's status(read by command~AA0) will be 04, and the output command will be ignored.

## 1.6 Dual Watchdog Operation for DIO, AIO

### Dual Watchdog=Module Watchdog + Host Watchdog

The Module Watchdog is a hardware reset circuit to monitor the module's operating status. While working in harsh or noisy environment, the module may be down by the external signal. The circuit may let the module to work continues and never halt.

The Host Watchdog is a software function to monitor the host's operating status. Its purpose is to prevent the network from communication problem or host halt. When the timeout interval expired, the module will turn all outputs to predefined Safe Value. This can prevent the controlled target from unexpected situation.

The EX9000 module with Dual Watchdog may let the control system more reliable and stable.

## 1.7 Reset Status

The Reset Status is set while the module power on or reset by module watchdog and is cleared while the command read Reset Status (\$AA5) applied. This is useful for user to check the module's working status. When the Reset Status is set means the module is reset and the output may be changed to the PowerOn Value. When the Reset Status is clear means the module is not rested and the output is not changed.

# 1.8 Calibration

Calibration Requirement for EX9017 series. While calibrate type 0D, the EX9017 series need connect external shunt resistor, 125Ohms, 0.1%

Type code	08	09	0A	0B	0C	0D
Zero Input	0V	0V	0V	0mV	0mV	0mA
Span	+10V	+5V	+1V	+500mV	+150mV	+20mA

### Calibration Sequence:

1. Connect calibration voltage/current to module's channel 0.
2. Warm-Up for 30 minutes
3. Set the input type of module which you wish to calibration.
4. Enable Calibration (P.24)
5. Apply Zero Calibration Voltage
6. Perform Zero Calibration Command (P.16)
7. Apply Span Calibration Voltage
8. Perform Span Calibration Command (P.15)
9. Repeat step4 to step 8 three times.

**Warning:** Please don't calibrate before you really understand.

# 1.9 Configuration Tables

## Baud Rate Setting (CC)

Code	03	04	05	06	07	08	09	0A
Baud rate	1200	2400	4800	9600	19200	38400	57600	115200

## Sensor Type & V/I Range Setting (TT)

Code	Range	Format	+F.S.	Zero	-F.S.
08	-10~+10V	Engineer unit	+10.000	+00.000	-10.000
		% of F.S.R.	+100.00	+000.00	-100.00
		2's complement	7FFF	0000	8000
09	-5~+5V	Engineer unit	+5.0000	+0.0000	-5.0000
		% of F.S.R.	+100.00	+000.00	-100.00
		2's complement	7FFF	0000	8000
0A	-1~+1V	Engineer unit	+1.0000	+0.0000	-1.0000
		% of F.S.R.	+100.00	+000.00	-100.00
		2's complement	7FFF	0000	8000
0B	-500~+500mV	Engineer unit	+500.00	+000.00	-500.00
		% of F.S.R.	+100.00	+000.00	-100.00
		2's complement	7FFF	0000	8000
0C	-150~+150mV	Engineer unit	+150.00	+000.00	-150.00
		% of F.S.R.	+100.00	+000.00	-100.00
		2's complement	7FFF	0000	8000
0D	-20~+20mA	Engineer unit	+20.000	+00.000	-20.000
		% of F.S.R.	+100.00	+000.00	-100.00
		2's complement	7FFF	0000	8000

## Data Format Setting (FF)

7	6	5	4	3	2	1	0
FS	CS	reserved				DF	

Key	Description
DF	Data format 00: Engineering unit 01: % of FSR (full scale range) 10: 2's complement hexadecimal
CS	Checksum setting 0: Disabled 1: Enabled
FS	Filter setting 0: 60Hz rejection 1: 50Hz rejection

**Note:** The reserved bits should be zero.



## 2.2 #AA

**Description:** Read Analog Input

**Syntax:** #AA[CHK](cr)

# delimiter character

AA address of reading/response module(00 to FF)

**Response:** Valid Command: >(Data)

(Data) analog input value for its format while use #AA command to EX9017F, the data is the combination for each channel respectively.

### **Example :**

Command :#01 Receive : >+02.635

Read address 01, get data successfully.

Command : #02 Receive : >4C53

Read address 02, get data in HEX format successfully.

Command : #04

Receive:>+05.123+04.153+07.234-02.356+10.000-05.133+02.345+08.234

The module address 04 is EX9017. Read address 04 for getting data of all 8 channels.







## 2.6 \$AA2

**Description:** Read configuration.

**Syntax:** \$AA2[CHK](cr)

\$ delimiter character

AA address of reading/response module (00 to FF)

2 command for read configuration

**Response:** Valid Command:     !**AATTCCFF**

Invalid Command:    ?**AA**

TT type code of module

CC baudrate code of module

FF data format of module

**Example:**

Command: \$012

Receive: !01080600

Read the configuration of module 01, input range of -10~+10V, baudrate 9600, no checksum.

**Note: check configuration Tables**



## 2.8 \$AA6

**Description:** Read Channel Status

**Syntax:** \$AA6[CHK](cr)

\$ delimiter character

AA address of reading/response module (00 to FF)

6 command for read channel status

**Response:** Valid Command: !AAVV

Invalid Command: ?AA

VV are two hexadecimal values. The values are interpreted by the module as two binary words (4-bit). The first word represents the status of channel 4~7, and the second word represents the status of channel 0~3. Value 0 means the channel is disabled, value 1 means the channel is enabled.

### **Example:**

Command :\$0152A                      Receive : !01

Set address 01 to enable channel 1,3,5 and disable channel 0,2,4,6,7 return success.

Command : \$016                                      Receive : !012A

Reads Read address 01 channel status, return channel 1,3,5 are enabled and channel 0,2,4,6,7 are disabled.

## 2.9 \$AAF

**Description:** Read Firmware Version

**Syntax:** \$AAF[CHK](cr)

\$ delimiter character

AA address of reading/response module(00 to FF)

F command for read firmware version

**Response:** Valid command: **!AA(Data)**

Invalid command: **?AA**

(Data) Firmware version of module

**Example:**

Command : \$01F

Receive : !01M6.92

Read address 01 firmware version, return version M6.92

## 2.10 \$AAM

**Description:** Read Module Name

**Syntax:** \$AAM[CHK](cr)

\$ delimiter character

AA address of reading/response module(00 to FF)

M command for read module name

**Response:** Valid command: **!AA(Data)**

Invalid command: **?AA**

(Data) Name of module

**Example:**

Command : \$01M

Receive : !019017

Read address 01 module name, return name 9017.



## 2.12 ~AAO(Data)

**Description:** Set Module Name

**Syntax:** ~AAO(Data)[CHK](cr)

~ delimiter character

AA address of setting/response module(00 to FF)

O command for set module name

(Data) new name for module, max 6 characters

**Response:** Valid command:           !AA

                  Invalid command:       ?AA

**Example:**

Command:~01O9017

Receive :!01

Set address 01 module name 9017, return success.

## 2.13 ~\*\*

**Description:** Host OK.

Host send this command to all modules for send the information "Host OK"

**Syntax:** ~\*\*[CHK](cr)

~ delimiter character

\*\* command for all modules

**Response:** No response.

**Example:**

Command: ~\*\*            No response

## 2.14 ~AA0

**Description:** Read Module Host Watchdog Status.

**Syntax:** ~AA0[CHK](cr)

~ delimiter character

AA address of reading/response module(00 to FF)

0 command for read module status

**Response:** Valid command:           **!AASS**

                  Invalid command:       **?AA**

SS module status, 00=host watchdog timeout status is clear,04=host watchdog timeout status is set. The status will store into EEPROM and only may reset by the command~AA1.

## 2.15 ~AA1

**Description:** Reset Module Host Watchdog Status.

**Syntax:** ~AA1[CHK](cr)

~ delimiter character

AA address of setting/response module(00 to FF)

1 command for reset module status

**Response:** Valid command:            !**AA**

                  Invalid command:       ?**AA**

## 2.16 ~AA2

**Description:** Read Host Watchdog Timeout Value

**Syntax:** ~AA2[CHK](cr)

~ delimiter character

AA address of reading/response module(00 to FF)

2 command for read host watchdog timeout value

**Response:** Valid command :           !AAEVV

                  Invalid command:       ?AA

E host watchdog enable status, 1=Enable, 0=Disable

VV timeout value in HEX format, each count is 0.1 second

01=0.1 second and FF=25.5 seconds



Read address 01 module status, return host watchdog timeout status is set.

Command : ~012

Receive : !01064

Read address 01 host watchdog timeout value, return that host watchdog is disabled, and time interval is 10.0 seconds.

Command : ~011

Receive : !01

Reset address 01 host watchdog timeout status, return success And the LED of this module stop flash.

Command : ~010

Receive : !0100

Read address 01 module status, return host watchdog timeout status is clear.